



Remove the six Phillips screws from the control board. Gently pull the control panel out and tilt it back.